

DOMO 01-1320

Zásuvka RTV průběžná



DOMO 01-1320-002 bi




| | | |
|---------------------|--------------|----------------|
| DOMO 01-1320-002 bi | 24745 | bílá |
| DOMO 01-1320-003 kr | 24804 | krémová |
| DOMO 01-1320-043 sr | 24863 | stříbrná |
| DOMO 01-1320-041 gr | 24922 | grafit |
| DOMO 01-1320-030 pe | 24981 | perleťově bílá |
| DOMO 01-1320-050 sz | 25040 | šampaňská |

- Plast: PC
- Materiál: PC

DOMO 01-1320


Zásuvka RTV průběžná



DOMO 01-1320-002 bi



DOMO 01-1320-003 kr



DOMO 01-1320-043 sr




DOMO 01-1320-041 gr




DOMO 01-1320-030 pe




DOMO 01-1320-050 sz




DOMO 01-1320-002 bi



DOMO 01-1320-003 kr




DOMO 01-1320-043 sr




DOMO 01-1320-041 gr

DOMO 01-1320

Zásuvka RTV průběžná



DOMO 01-1320-030 pe



DOMO 01-1320-050 sz